CHOKKA BLOCK

ROOF ALIGNMENT GUIDE | INSTALLATION INSTRUCTIONS

Suitable for the relevant CHOKKA BLOCK-compatible pop-top roof configurations. Always check actual clearance, alignment and secure positioning before use.

1 Identify the correct position

Raise and safely support the pop-top roof. Position each block **directly above its corresponding roof clamp**, on the flat roof-edge surface shown. Keep the block clear of the black roof seal, brackets, welds and moving components.



Position example: block sits on the ledge above the clamp, with the sloped face oriented to guide roof alignment.

2 Prepare and check

Clean the contact surface, removing dust, wax and grease. Use a suitable wax-and-grease remover according to its label, allow it to fully evaporate and check compatibility with painted surfaces. Dry-fit all four blocks and carefully test roof movement before fixing anything.

3 Choose your installation method

A. Screw: Each block has a **6 mm mounting hole**. Use a suitable fastener and mounting method for the caravan structure. Check for hidden wiring and waterproof any penetrations. Do not drill without confirming structural suitability.

B. Glue: Selleys Liquid Nails Clear is the adhesive shown in the demonstration. Use only if its current manufacturer instructions confirm suitability for the specific block material and caravan surface. Apply to a clean, dry, wax-and-grease-free surface and allow the full recommended cure time before use.

C. Sit loose: Blocks may be positioned loose for alignment checks. **I personally sit mine loose and have experienced no issues.** This is personal experience, not a guarantee that loose blocks will remain secure on

other caravans. Remove or positively secure loose blocks before travel and whenever they could fall or shift.

4 Final check

With a second person observing where practical, lower the roof slowly and confirm each block guides rather than jams the roof. Check the seal, roof clamps, struts and moving arms are unobstructed. Stop immediately if resistance or interference occurs.

INSTALLATION REFERENCE PHOTOS






Adhesive shown in video | Roof movement and support-arm clearance | Roof clamp location

Safety: Do not rely on the blocks to support the roof or replace roof clamps. Never place hands in closing gaps. Installation and use remain subject to the caravan manufacturer's safety instructions.

CHOKKA BLOCK | Kurt: 0451 101 624 | Australian designed and made